

cincoze

CS-100/P2202 Series

User Manual



Industrial Panel PC

High Performance Sunlight Readable Panel PC

Contents

Preface.....	5
Revision	5
Copyright Notice	5
Acknowledgement	5
Disclaimer.....	5
Declaration of Conformity.....	6
Product Warranty Statement	6
Technical Support and Assistance	8
Conventions Used in this Manual	8
Safety Precautions.....	9
Package Contents	10
Ordering Information	10
Chapter 1 Product Introductions	12
1.1 Overview	13
1.2 Specifications	14
1.2.1 CS-112HC/P2202 Series.....	14
1.2.2 CS-115C/P2202 Series	19
1.2.3 CS-117C/P2202 Series	24
1.2.4 CS-119C/P2202 Series	29
1.2.5 CS-W121C/P2202 Series.....	34
1.2.6 CS-W124C/P2202 Series.....	39
1.3 External Layout.....	44
1.3.1 Front	44
1.3.2 Rear.....	45
1.3.3 Left.....	46
1.3.4 Right.....	47
Chapter 2 Introduction to Switches and Connectors	48
2.1 Location of Switches and Connectors	49
2.1.1 Top View	49
2.1.2 Bottom View	49
2.2 Switches and Connectors Definition	50
2.3 Definition of Switches	51
2.4 Definition of Connectors	53
2.5 Optional Module Pin Definition & Settings.....	59
2.5.1 CFM-IGN101 Module.....	59
Chapter 3 System Setup	60
3.1 Removing the Top Cover	61
3.2 Installing Mini PCIe Card(s)	62

3.3 Installing a M.2 E Key Card	63
3.4 Installing Antenna(s)	64
3.5 Installing SO-DIMM(s)	65
3.6 Installing a PCI(e) Card	66
3.7 Installing Thermal Pad of Thermal Block.....	68
3.8 Installing the Top Cover	69
3.9 Disassemble the CS Display Module	69
3.10 Installing a SATA Hard Drive at Front Panel	70
3.11 Installing a SATA hard drive on Bottom Side	72
3.12 Installing a SIM Card.....	74
3.13 Installing CFM Modules.....	75
3.13.1 CFM-IGN101 Module.....	75
3.13.2 CFM-PoE04 Module.....	76
3.14 Installing MEC Modules.....	78
3.14.1 MEC-COM-M212-TDB9/UB1203 Module.....	78
3.14.2 MEC-COM-M334-TDB9/UB1203 Module.....	81
3.14.3 MEC-USB-M102-30/UB1214 Module.....	84
3.14.4 MEC-LAN-M102-30/UB1211 Module.....	87
3.15 Installing Panel Mount	90
3.16 Installing VESA Mount	94
3.17 Installing Rack Mount.....	95
Chapter 4 BIOS Setup	97
4.1 BIOS Introduction	98
4.2 Main Setup	99
4.3 Advanced Setup	100
4.3.1 CPU Configuration	100
4.3.2 SATA Configuration	101
4.3.3 PCH-FW Configuration.....	101
4.3.4 Trusted Computing.....	102
4.3.5 ACPI Settings.....	103
4.3.6 F81966 Super IO Configuration	104
4.3.7 Hardware Monitor.....	105
4.3.8 S5 RTC Wake Settings.....	106
4.3.9 Serial Port Console Redirection.....	106
4.3.10 USB Configuration	107
4.3.11 Network Stack Configuration	107
4.3.12 CSM Configuration	108
4.4 Chipset Setup	108
4.4.1 System Agent (SA) Configuration	109
4.4.2 PCH-IO Configuration	112

4.5 Security Setup	114
4.6 Boot Setup.....	115
4.7 Save & Exit.....	116
4.8 MEBx	117
Chapter 5 Product Application	120
5.1 Where to download drivers?	121
5.2 Where to find the technical documents?	錯誤! 尚未定義書籤。

Preface

Revision

Revision	Description	Date
1.00	First Released	2023/11/17
1.01	Correction Made	2024/02/07
1.10	OS Spec Updated	2024/04/26
1.11	Power Spec Updated	2024/12/31

Copyright Notice

© 2023 by Cincoze Co., Ltd. All rights are reserved. No parts of this manual may be copied, modified, or reproduced in any form or by any means for commercial use without the prior written permission of Cincoze Co., Ltd. All information and specification provided in this manual are for reference only and remain subject to change without prior notice.

Acknowledgement

Cincoze is a registered trademark of Cincoze Co., Ltd. All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Disclaimer

This manual is intended to be used as a practical and informative guide only and is subject to change without notice. It does not represent a commitment on the part of Cincoze. This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Declaration of Conformity



FCC

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



CE

The product(s) described in this manual complies with all application European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

Product Warranty Statement

Warranty

Cincoze products are warranted by Cincoze Co., Ltd. to be free from defect in materials and workmanship for 2 years from the date of purchase by the original purchaser. During the warranty period, we shall, at our option, either repair or replace any product that proves to be defective under normal operation. Defects, malfunctions, or failures of the warranted product caused by damage resulting from natural disasters (such as by lightening, flood, earthquake, etc.), environmental and atmospheric disturbances, other external forces such as power line disturbances, plugging the board in under power, or incorrect cabling, and damage caused by misuse, abuse, and unauthorized alteration or repair, and the product in question is either software, or an expendable item (such as a fuse, battery, etc.), are not warranted.

RMA

Before sending your product in, you will need to fill in Cincoze RMA Request Form and obtain an RMA number from us. Our staff is available at any time to provide you with the most friendly and immediate service.

■ RMA Instruction

- Customers must fill in Cincoze Return Merchandise Authorization (RMA) Request Form and obtain an RMA number prior to returning a defective product to Cincoze for service.
- Customers must collect all the information about the problems encountered and note anything abnormal and describe the problems on the "Cincoze Service Form" for the RMA number apply process.
- Charges may be incurred for certain repairs. Cincoze will charge for repairs to products whose warranty period has expired. Cincoze will also charge for repairs to products if the damage resulted from acts of God, environmental or atmospheric disturbances, or other external forces through misuse, abuse, or unauthorized alteration or repair. If charges will be incurred for a repair, Cincoze lists all charges, and will wait for customer's approval before performing the repair.
- Customers agree to ensure the product or assume the risk of loss or damage during transit, to prepay shipping charges, and to use the original shipping container or equivalent.
- Customers can be sent back the faulty products with or without accessories (manuals, cable, etc.) and any components from the system. If the components were suspected as part of the problems, please note clearly which components are included. Otherwise, Cincoze is not responsible for the devices/parts.
- Repaired items will be shipped along with a "Repair Report" detailing the findings and actions taken.

Limitation of Liability

Cincoze' liability arising out of the manufacture, sale, or supplying of the product and its use, whether based on warranty, contract, negligence, product liability, or otherwise, shall not exceed the original selling price of the product. The remedies provided herein are the customer's sole and exclusive remedies. In no event shall Cincoze be liable for direct, indirect, special or consequential damages whether based on contract of any other legal theory.

Technical Support and Assistance

1. Visit the Cincoze website at www.cincoze.com where you can find the latest information about the product.
2. Contact your distributor or our technical support team or sales representative for technical support if you need additional assistance. Please have following information ready before you call:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

Conventions Used in this Manual



WARNING

This indication alerts operators to an operation that, if not strictly observed, may result in severe injury.



CAUTION

This indication alerts operators to an operation that, if not strictly observed, may result in safety hazards to personnel or damage to equipment.



NOTE

This indication provides additional information to complete a task easily.

Safety Precautions

Before installing and using this device, please note the following precautions.

1. Read these safety instructions carefully.
2. Keep this User's Manual for future reference.
3. Disconnect this equipment from any AC outlet before cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
7. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
8. Use a power cord that has been approved for using with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.

If one of the following situations arises, get the equipment checked by service personnel:

- The power cord or plug is damaged.
 - Liquid has penetrated into the equipment.
 - The equipment has been exposed to moisture.
 - The equipment does not work well, or you cannot get it work according to the user's manual.
 - The equipment has been dropped and damaged.
 - The equipment has obvious signs of breakage.
14. CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.
 15. Equipment intended only for use in a RESTRICTED ACCESS AREA.
 16. Ensure to connect the power cord of power adapter to a socket-outlet with earthing connection.
 17. Dispose of used battery promptly. Keep away from children. Do not disassemble and do not dispose of in fire.

Package Contents

Before installation, please ensure all the items listed in the following table are included in the package.

Item	Description	Q'ty
1	CS-100/P2202 Series Panel PC	1
2	Thermal Pad (for CPU Thermal Block)	1
3	Power Terminal Block Connector	1
4	Remote Power On/Off Terminal Block Connector	1
5	DIO Terminal Block Connector	2
6	Screws Pack	5
7	PCI / PCIe Card Installation Kit (For CS-100/P2202E Only)	1
8	Panel Mounting Kit (The quantity varies with the size of the display module, please refer to the datasheet for the actual quantity)	1

Note: Notify your sales representative if any of the above items are missing or damaged.

Ordering Information

Available Models

Model No.	Product Description
CS-112HC/P2202-i5	12.1" 1500 nits TFT-LCD Sunlight Readable and Modular Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-112HC/P2202E-i5	12.1" 1500nits TFT-LCD Sunlight Readable, Modular and Expandable Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-112HC/P2202-i3	12.1" 1500nits TFT-LCD Sunlight Readable and Modular Panel PC with 12th Gen. Intel® Core™ i3-1215UE Processor and Projected Capacitive Touch
CS-112HC/P2202E-i3	12.1" 1500nits TFT-LCD Sunlight Readable, Modular and Expandable Panel PC with 12th Gen. Intel® Core™ i3-1215UE Processor and Projected Capacitive Touch
CS-115C/P2202-i5	15" 1800nits TFT-LCD Sunlight Readable and Modular Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-115C/P2202E-i5	15" 1800nits TFT-LCD Sunlight Readable, Modular and Expandable Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-115C/P2202-i3	15" 1800nits TFT-LCD Sunlight Readable and Modular Panel PC with 12th Gen. Intel® Core™ i3-1215UE Processor and Projected Capacitive Touch
CS-115C/P2202E-i3	15" 1800nits TFT-LCD Sunlight Readable, Modular and Expandable Panel PC

	with 12th Gen. Intel® Core™ i3-1215UE Processor and Projected Capacitive Touch
CS-117C/P2202-i5	17" 1500nits TFT-LCD Sunlight Readable and Modular Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-117C/P2202E-i5	17" 1500nits TFT-LCD Sunlight Readable, Modular and Expandable Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-117C/P2202-i3	17" 1500nits TFT-LCD Sunlight Readable and Modular Panel PC with 12th Gen. Intel® Core™ i3-1215UE Processor and Projected Capacitive Touch
CS-117C/P2202E-i3	17" 1500nits TFT-LCD Sunlight Readable, Modular and Expandable Panel PC with 12th Gen. Intel® Core™ i3-1215UE Processor and Projected Capacitive Touch
CS-119C/P2202-i5	19" 1600nits TFT-LCD Sunlight Readable and Modular Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-119C/P2202E-i5	19" 1600nits TFT-LCD Sunlight Readable, Modular and Expandable Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-119C/P2202-i3	19" 1600nits TFT-LCD Sunlight Readable and Modular Panel PC with 12th Gen. Intel® Core™ i3-1215UE Processor and Projected Capacitive Touch
CS-119C/P2202E-i3	19" 1600nits TFT-LCD Sunlight Readable, Modular and Expandable Panel PC with 12th Gen. Intel® Core™ i3-1215UE Processor and Projected Capacitive Touch
CS-W121C/P2202-i5	21.5" Full HD TFT-LCD Modular Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-W121C/P2202E-i5	21.5" Full HD TFT-LCD Modular and Expandable Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-W121C/P2202-i3	21.5" Full HD TFT-LCD Modular Panel PC with 12th Gen. Intel® Core™ i3-1215UE Dual Core Processor and Projected Capacitive Touch
CS-W121C/P2202E-i3	21.5" Full HD TFT-LCD Modular and Expandable Panel PC with 12th Gen. Intel® Core™ i3-1215UE Dual Core Processor and Projected Capacitive Touch
CS-W124C/P2202-i5	24" Full HD TFT-LCD Modular Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-W124C/P2202E-i5	24" Full HD TFT-LCD Modular and Expandable Panel PC with 12th Gen. Intel® Core™ i5-1245UE Processor and Projected Capacitive Touch
CS-W124C/P2202-i3	24" Full HD TFT-LCD Modular Panel PC with 12th Gen. Intel® Core™ i3-1215UE Dual Core Processor and Projected Capacitive Touch
CS-W124C/P2202E-i3	24" Full HD TFT-LCD Modular and Expandable Panel PC with 12th Gen. Intel® Core™ i3-1215UE Dual Core Processor and Projected Capacitive Touch



Chapter 1

Product Introductions

1.1 Overview

The CS-100/P2202 series is a sunlight-readable high-performance panel PC that provides ultra-high brightness of up to 1,800 nits. It is equipped with an Intel® Core™ U-series (Alder Lake-P) processor that provides a complete selection of screen sizes, ratios, and brightnesses. Rich I/O, flexible expansion, rugged, easy on-site maintenance, and other features make the CS-100/P2202 series the best choice for outdoor kiosk or HMI applications.

- TFT-LCD with Projected Capacitive Touch
- Onboard Intel® Alder Lake-P U-Series Core™ Processor
- 2x DDR5 SO-DIMM Socket, Supports up to 4800MHz 64GB Memory
- Ultra High Brightness up to 1,500 nits
- Quad Independent Display (CDS / HDMI / DP / VGA)
- 1x M.2 Key E Type 2230 Socket for Intel CNVi / Wireless Module
- Designed with Aluminum Die-cast Front Bezel
- Front Panel IP65 Compliant



Excellent Computing Performance

The CS-100/P2202 series is equipped with the 12th Gen Intel® Core™ i5/i3 U-series (Alder Lake-P) processor based on the Intel® 7 process. The U-series has a low power consumption of only 15W, boasts excellent performance with up to 10 cores (2P+8E), and includes the built-in Intel® Iris Xe graphics to easily handle image classification inference performance in AI deep learning

i5 Processor



i3 Processor



CDS Patented Technology

Cincoze Convertible Display System (CDS) patented technology makes field-side maintenance and future upgrades easier. Replacing a display or improving system performance only requires replacing a single component, which significantly cuts upgrade costs.

Patent No. M482908

Complete Range of Sizes

The CS-100/P2202 series offers a variety of display options, with screen sizes from 12 to 24 inches, support for up to full HD resolution, high brightness up to 1,800 nits, and multi-point P-Cap touchscreen, which can be selected according to application needs.



Wide Temps, Safe, Reliable

In order to overcome the harsh outdoor environment and unpredictable climate, the CS-100/P2202 series has a series of industrial-grade protections, including a wide operating temperature range that beats the industry standard and an IP65 dustproof/water resistant front panel to ensure a high degree of product safety.



1.2 Specifications

1.2.1 CS-112HC/P2202 Series

Model Name	CS-112HC
Display	
LCD Size	• 12.1" (4:3)
Max. Resolution	• 1024 x 768
Brightness (cd/m2)	• 1500
Contrast Ratio	• 700 : 1
LCD Color	• 16.7M
Pixel Pitch	• 0.24 (H) x 0.24 (V)
Viewing Angle	• 160 / 160
Backlight MTBF	• 30,000 hrs (LED Backlight)
Touchscreen	
Touchscreen Type	• Projected Capacitive
Physical	
Dimension (WxDxH)	• 345 x 265.3 x 57 mm
Weight	• 3.16 kg
Construction	• Flat Rugged Aluminum Die-casting Bezel
Power	
Power Consumption	• 16.22W (Typ.)
Environment	
Front Panel Protection	• IP 65 Compliant
Operating Temperature	• -20°C to 80°C (With Industrial Grade Peripherals; Ambient with air flow)
Storage Temperature	• -30°C to 80°C
Relative Humidity	• 90% RH @ 40°C (non-condensing)
EMC	• CE, UKCA, FCC, ICES-003 Class A
EMI	• CISPR 32 Conducted & Radiated: Class A • EN/BS EN 55032 Conducted & Radiated: Class A • EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A • EN/BS EN61000-3-3 Voltage fluctuations & flicker • FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	• EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV • EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 3 V/m • EN/IEC 61000-4-4 EFT: AC Power: 1 kV; DC Power: 0.5 kV; Signal: 0.5 kV • EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV • EN/IEC 61000-4-6 CS: 3V • EN/IEC 61000-4-8 PFMF: 50 Hz, 1A/m • EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 0.5 cycles at 50 Hz

Safety	• UL, cUL, CB, IEC, EN 62368-1	
Model Name	P2202	P2202E
System		
Processor	- Onboard 12th Generation Intel® Alder Lake-P U-Series CPU: - Intel® Core™ i5-1245UE 10 Cores Up to 4.40 GHz, TDP 15W - Intel® Core™ i3-1215UE 6 Cores Up to 4.40 GHz, TDP 15W	
Memory	2x DDR5 4800MHz SO-DIMM Socket Supports Un-buffered and non-ECC Type, Up to 64GB	
BIOS	AMI BIOS	
Graphics		
Graphics Engine	- Integrated Intel® Iris® Xe Graphics: Core™ i5-1245UE - Integrated Intel® UHD Graphics: Core™ i3-1215UE	
Maximum Display Output	Supports Quad Independent Display	
CDS	1x CDS Connector (1920 x 1080 @60Hz)	
DP	1x DisplayPort Connector (4096 x 2304 @60Hz) * Verified maximum resolution: 3840 x 2160 @ 60Hz	
HDMI	1x HDMI Connector (3840 x 2160 @30Hz)	
VGA	1x VGA Connector (1920 x 1200 @60Hz)	
Audio		
Audio Codec	Realtek® ALC888, High Definition Audio	
Line-out	1x Line-out, Phone Jack 3.5mm	
Mic-in	1x Mic-in, Phone Jack 3.5mm	
I/O		
LAN	2x 1GbE LAN, RJ45 - GbE1: Intel® I219 - GbE2: Intel® I210	
COM	4x RS-232/422/485 with Auto Flow Control (Supports 5V/12V), DB9	
USB	3x 10Gbps USB 3.2 Gen2x1, Type A 1x 480Mbps USB 2.0, Type A	
DIO	16x Isolated Digital I/O (8in/8out), 20-Pin Terminal Block	
Storage		
SSD/HDD	2x 2.5” SATA HDD/SSD Bay (SATA3.0)	
RAID	Support RAID 0/1	
Expansion		
Mini PCI Express	2x Full-size Mini-PCIe Socket	
PCI Express	--	1x PCI or 1x PCIe x4 Expansion slot (with Optional Riser Card) * Supports maximum dimensions of

		add-on card (H x L):169 x 111mm
SIM Socket	1x SIM Socket	
M.2	1x M.2 Key E Type 2230 Socket, Support Intel CNVi/Wireless Module	
CFM (Control Function Module) Interface	1x CFM Interface for optional IGN Module Expansion 1x CFM Interface for optional PoE Module Expansion	
CDS (Convertible Display System) Interface	1x CDS Interface for Convertible Display Module	
Other Function		
Clear CMOS Switch	1x Clear CMOS Switch	
Reset Button	1x Reset Button	
Instant Reboot	Support 0.2sec Instant Reboot Technology	
Watchdog Timer	Software Programmable Supports 256 Levels System Reset	
OSD Button	LCD On/Off, Brightness Up, Brightness Down	
Internal Speaker	AMP 2W + 2W	
Status LED Indicator	Power LED, HDD LED	
Power		
Power Button	1x ATX Power On/Off Button	
Power Mode Switch	1x AT/ATX Mode Switch	
Power Input	9 - 48VDC, 3-pin Terminal Block	
Remote Power On/Off	1x Remote Power On/Off, 2-pin Terminal Block	
Max. Power Consumption	- i5-1245UE CPU: 95.06W - Test conducted with CPU, 1x RAM, and 1x storage - 100% load during burn-in testing.	
Inrush Current (Peak)	i5-1245UE CPU: 5.381 A@24V	
Operating System		
Windows	Windows®11, Windows®10	
Linux	Ubuntu Desktop 22.04 LTS	
Physical		
Dimension (W x D x H)	254.5 X 190 X 41.5 mm	254.5 x 190 x 61 mm
Weight Information	2.22 kg	2.74 kg
Mechanical Construction	Extruded Aluminum with Heavy Duty Metal	
Mounting	Wall / VESA / CDS / DIN Rail	
Physical Design	- Fanless Design - Jumper-less Design	
Reliability & Protection		
Reverse Power Input Protection	Yes	
Over Voltage Protection	- Protection Range: 51-58V - Protection Type: shut down operating voltage, re-power on at the present level to recover	


Over Current Protection	15A
CMOS Battery Backup	SuperCap Integrated for CMOS Battery Maintenance-free Operation
MTBF	216,747 Hours - Database: Telcordia SR-332 Issue3, Method 1, Case 3
Environment	
Operating Temperature	-40°C to 70°C - With extended temperature peripherals; Ambient with air flow - According to IEC60068-2-1, IEC60068-2-2, IEC60068-2-14
Storage Temperature	-40°C to 70°C
Relative Humidity	95%RH @ 70°C (non-Condensing)
Shock	Operating, 50 Grms (w/ SSD, according to IEC60068-2-27)
Vibration	- Operating, 1 Grms, 10-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-6) - Operating, 5 Grms, 5-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-64)
EMC	- CE, UKCA, FCC, ICES-003 Class A - EN IEC 61000-6-4, EN61000-6-2 (24VDC Input Only)
EMI	- CISPR 32 Conducted & Radiated: Class A - EN/BS EN 55032 Conducted & Radiated: Class A - EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A - EN/BS EN61000-3-3 Voltage fluctuations & flicker - FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	- EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV - EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 10 V/m - EN/IEC 61000-4-4 EFT: AC Power: 2 kV; DC Power: 1 kV; Signal: 1 kV - EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV - EN/IEC 61000-4-6 CS: 10V - EN/IEC 61000-4-8 PFMF: 50 Hz, 30A/m - EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 1 cycles at 60 Hz
Safety	uL, cUL, CB, IEC, EN 62368-1

** Product Specifications and features are for reference only and are subject to change without prior notice. For more information, please refer to the latest product datasheet from Cincoze's website.*

Dimensions


CS-112HC/P2202

unit: mm



CS-112HC/P2202E

unit: mm



1.2.2 CS-115C/P2202 Series

Model Name	CS-115C
Display	
LCD Size	• 15" (4:3)
Max. Resolution	• 1024 x 768
Brightness (cd/m2)	• 1800
Contrast Ratio	• 800 : 1
LCD Color	• 16.2M
Pixel Pitch	• 0.297 (H) x 0.297(V)
Viewing Angle	• 160 / 150
Backlight MTBF	• 50,000 hrs (LED Backlight)
Touchscreen	
Touchscreen Type	• Projected Capacitive
Physical	
Dimension (WxDxH)	• 408 x 312.4 x 59.2 mm
Weight	• 4.36kg
Construction	• Flat Rugged Aluminum Die-casting Bezel
Power	
Power Consumption	• 27.26W (Max.)
Environment	
Front Panel Protection	• IP 65 Compliant
Operating Temperature	• -20°C to 70°C (With Industrial Grade Peripherals; Ambient with air flow)
Storage Temperature	• -30°C to 70°C
Relative Humidity	• 90% RH @ 40°C (non-condensing)
EMC	• CE, UKCA, FCC, ICES-003 Class A
EMI	• CISPR 32 Conducted & Radiated: Class A • EN/BS EN 55032 Conducted & Radiated: Class A • EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A • EN/BS EN61000-3-3 Voltage fluctuations & flicker • FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	• EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV • EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 3 V/m • EN/IEC 61000-4-4 EFT: AC Power: 1 kV; DC Power: 0.5 kV; Signal: 0.5 kV • EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV • EN/IEC 61000-4-6 CS: 3V • EN/IEC 61000-4-8 PFMF: 50 Hz, 1A/m • EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 0.5 cycles at 50 Hz
Safety	• UL, cUL, CB, IEC, EN 62368-1

Model Name	P2202	P2202E
System		
Processor	- Onboard 12th Generation Intel® Alder Lake-P U-Series CPU: - Intel® Core™ i5-1245UE 10 Cores Up to 4.40 GHz, TDP 15W - Intel® Core™ i3-1215UE 6 Cores Up to 4.40 GHz, TDP 15W	
Memory	2x DDR5 4800MHz SO-DIMM Socket - Supports Un-buffered and non-ECC Type, Up to 64GB	
BIOS	AMI BIOS	
Graphics		
Graphics Engine	- Integrated Intel® Iris® Xe Graphics: Core™ i5-1245UE - Integrated Intel® UHD Graphics: Core™ i3-1215UE	
Maximum Display Output	Supports Quad Independent Display	
CDS	1x CDS Connector (1920 x 1080 @60Hz)	
DP	1x DisplayPort Connector (4096 x 2304 @60Hz) * Verified maximum resolution: 3840 x 2160 @ 60Hz	
HDMI	1x HDMI Connector (3840 x 2160 @30Hz)	
VGA	1x VGA Connector (1920 x 1200 @60Hz)	
Audio		
Audio Codec	Realtek® ALC888, High Definition Audio	
Line-out	1x Line-out, Phone Jack 3.5mm	
Mic-in	1x Mic-in, Phone Jack 3.5mm	
I/O		
LAN	2x 1GbE LAN, RJ45 - GbE1: Intel® I219 - GbE2: Intel® I210	
COM	4x RS-232/422/485 with Auto Flow Control (Supports 5V/12V), DB9	
USB	3x 10Gbps USB 3.2 Gen2x1, Type A 1x 480Mbps USB 2.0, Type A	
DIO	16x Isolated Digital I/O (8in/8out), 20-Pin Terminal Block	
Storage		
SSD/HDD	2x 2.5” SATA HDD/SSD Bay (SATA3.0)	
RAID	Support RAID 0/1	
Expansion		
Mini PCI Express	2x Full-size Mini-PCIe Socket	
PCI Express	--	1x PCI or 1x PCIe x4 Expansion slot (with Optional Riser Card) * Supports maximum dimensions of add-on card (H x L):169 x 111mm
SIM Socket	1x SIM Socket	

M.2	1x M.2 Key E Type 2230 Socket, Support Intel CNVi/Wireless Module
CFM (Control Function Module) Interface	1x CFM Interface for optional IGN Module Expansion 1x CFM Interface for optional PoE Module Expansion
CDS (Convertible Display System) Interface	1x CDS Interface for Convertible Display Module
Other Function	
Clear CMOS Switch	1x Clear CMOS Switch
Reset Button	1x Reset Button
Instant Reboot	Support 0.2sec Instant Reboot Technology
Watchdog Timer	Software Programmable Supports 256 Levels System Reset
OSD Button	LCD On/Off, Brightness Up, Brightness Down
Internal Speaker	AMP 2W + 2W
Status LED Indicator	Power LED, HDD LED
Power	
Power Button	1x ATX Power On/Off Button
Power Mode Switch	1x AT/ATX Mode Switch
Power Input	9 - 48VDC, 3-pin Terminal Block
Remote Power On/Off	1x Remote Power On/Off, 2-pin Terminal Block
Max. Power Consumption	- i5-1245UE CPU: 95.06W - Test conducted with CPU, 1x RAM, and 1x storage - 100% load during burn-in testing.
Inrush Current (Peak)	i5-1245UE CPU: 5.381 A@24V
Operating System	
Windows	Windows®11, Windows®10
Linux	Ubuntu Desktop 22.04 LTS
Physical	
Dimension (W x D x H)	254.5 X 190 X 41.5 mm 254.5 x 190 x 61 mm
Weight Information	2.22 kg 2.74 kg
Mechanical Construction	Extruded Aluminum with Heavy Duty Metal
Mounting	Wall / VESA / CDS / DIN Rail
Physical Design	- Fanless Design - Jumper-less Design
Reliability & Protection	
Reverse Power Input Protection	Yes
Over Voltage Protection	- Protection Range: 51-58V - Protection Type: shut down operating voltage, re-power on at the present level to recover
Over Current Protection	15A
CMOS Battery Backup	SuperCap Integrated for CMOS Battery Maintenance-free Operation


MTBF	216,747 Hours - Database: Telcordia SR-332 Issue3, Method 1, Case 3
Environment	
Operating Temperature	-40°C to 70°C - With extended temperature peripherals; Ambient with air flow - According to IEC60068-2-1, IEC60068-2-2, IEC60068-2-14
Storage Temperature	-40°C to 70°C
Relative Humidity	95%RH @ 70°C (non-Condensing)
Shock	Operating, 50 Grms (w/ SSD, according to IEC60068-2-27)
Vibration	- Operating, 1 Grms, 10-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-6) - Operating, 5 Grms, 5-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-64)
EMC	- CE, UKCA, FCC, ICES-003 Class A - EN IEC 61000-6-4, EN61000-6-2 (24VDC Input Only)
EMI	- CISPR 32 Conducted & Radiated: Class A - EN/BS EN 55032 Conducted & Radiated: Class A - EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A - EN/BS EN61000-3-3 Voltage fluctuations & flicker - FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	- EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV - EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 10 V/m - EN/IEC 61000-4-4 EFT: AC Power: 2 kV; DC Power: 1 kV; Signal: 1 kV - EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV - EN/IEC 61000-4-6 CS: 10V - EN/IEC 61000-4-8 PFMF: 50 Hz, 30A/m - EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 1 cycles at 60 Hz
Safety	uL, cUL, CB, IEC, EN 62368-1

** Product Specifications and features are for reference only and are subject to change without prior notice. For more information, please refer to the latest product datasheet from Cincoze's website.*

Dimensions


CS-115C/P2202

unit: mm



CS-115C/P2202E

unit: mm



1.2.3 CS-117C/P2202 Series

Model Name	CS-117C
Display	
LCD Size	• 17" (5:4)
Max. Resolution	• 1280 x 1024
Brightness (cd/m2)	• 1500
Contrast Ratio	• 800 : 1
LCD Color	• 16.7M
Pixel Pitch	• 0.264 (H) x 0.264 (V)
Viewing Angle	• 160 / 140
Backlight MTBF	• 50,000 hrs (LED Backlight)
Touchscreen	
Touchscreen Type	• Projected Capacitive
Physical	
Dimension (WxDxH)	• 450 x 350 x 63.2mm
Weight	• 5.64 kg
Construction	• Flat Rugged Aluminum Die-casting Bezel
Power	
Power Consumption	• 30.65W (Typ.)
Environment	
Front Panel Protection	• IP 65 Compliant
Operating Temperature	• -20°C to 80°C (With Industrial Grade Peripherals; Ambient with air flow)
Storage Temperature	• -30°C to 80°C
Relative Humidity	• 90% RH @ 40°C (non-condensing)
EMC	• CE, UKCA, FCC, ICES-003 Class A
EMI	• CISPR 32 Conducted & Radiated: Class A • EN/BS EN 55032 Conducted & Radiated: Class A • EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A • EN/BS EN61000-3-3 Voltage fluctuations & flicker • FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	• EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV • EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 3 V/m • EN/IEC 61000-4-4 EFT: AC Power: 1 kV; DC Power: 0.5 kV; Signal: 0.5 kV • EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV • EN/IEC 61000-4-6 CS: 3V • EN/IEC 61000-4-8 PFMF: 50 Hz, 1A/m • EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 0.5 cycles at 50 Hz
Safety	• UL, cUL, CB, IEC, EN 62368-1

Model Name	P2202	P2202E
System		
Processor	- Onboard 12th Generation Intel® Alder Lake-P U-Series CPU: - Intel® Core™ i5-1245UE 10 Cores Up to 4.40 GHz, TDP 15W - Intel® Core™ i3-1215UE 6 Cores Up to 4.40 GHz, TDP 15W	
Memory	2x DDR5 4800MHz SO-DIMM Socket - Supports Un-buffered and non-ECC Type, Up to 64GB	
BIOS	AMI BIOS	
Graphics		
Graphics Engine	- Integrated Intel® Iris® Xe Graphics: Core™ i5-1245UE - Integrated Intel® UHD Graphics: Core™ i3-1215UE	
Maximum Display Output	Supports Quad Independent Display	
CDS	1x CDS Connector (1920 x 1080 @60Hz)	
DP	1x DisplayPort Connector (4096 x 2304 @60Hz) * Verified maximum resolution: 3840 x 2160 @ 60Hz	
HDMI	1x HDMI Connector (3840 x 2160 @30Hz)	
VGA	1x VGA Connector (1920 x 1200 @60Hz)	
Audio		
Audio Codec	Realtek® ALC888, High Definition Audio	
Line-out	1x Line-out, Phone Jack 3.5mm	
Mic-in	1x Mic-in, Phone Jack 3.5mm	
I/O		
LAN	2x 1GbE LAN, RJ45 - GbE1: Intel® I219 - GbE2: Intel® I210	
COM	4x RS-232/422/485 with Auto Flow Control (Supports 5V/12V), DB9	
USB	3x 10Gbps USB 3.2 Gen2x1, Type A 1x 480Mbps USB 2.0, Type A	
DIO	16x Isolated Digital I/O (8in/8out), 20-Pin Terminal Block	
Storage		
SSD/HDD	2x 2.5” SATA HDD/SSD Bay (SATA3.0)	
RAID	Support RAID 0/1	
Expansion		
Mini PCI Express	2x Full-size Mini-PCIe Socket	
PCI Express	--	1x PCI or 1x PCIe x4 Expansion slot (with Optional Riser Card) * Supports maximum dimensions of add-on card (H x L):169 x 111mm
SIM Socket	1x SIM Socket	

M.2	1x M.2 Key E Type 2230 Socket, Support Intel CNVi/Wireless Module
CFM (Control Function Module) Interface	1x CFM Interface for optional IGN Module Expansion 1x CFM Interface for optional PoE Module Expansion
CDS (Convertible Display System) Interface	1x CDS Interface for Convertible Display Module
Other Function	
Clear CMOS Switch	1x Clear CMOS Switch
Reset Button	1x Reset Button
Instant Reboot	Support 0.2sec Instant Reboot Technology
Watchdog Timer	Software Programmable Supports 256 Levels System Reset
OSD Button	LCD On/Off, Brightness Up, Brightness Down
Internal Speaker	AMP 2W + 2W
Status LED Indicator	Power LED, HDD LED
Power	
Power Button	1x ATX Power On/Off Button
Power Mode Switch	1x AT/ATX Mode Switch
Power Input	9 - 48VDC, 3-pin Terminal Block
Remote Power On/Off	1x Remote Power On/Off, 2-pin Terminal Block
Max. Power Consumption	- i5-1245UE CPU: 95.06W - Test conducted with CPU, 1x RAM, and 1x storage - 100% load during burn-in testing.
Inrush Current (Peak)	i5-1245UE CPU: 5.381 A@24V
Operating System	
Windows	Windows®11, Windows®10
Linux	Ubuntu Desktop 22.04 LTS
Physical	
Dimension (W x D x H)	254.5 X 190 X 41.5 mm 254.5 x 190 x 61 mm
Weight Information	2.22 kg 2.74 kg
Mechanical Construction	Extruded Aluminum with Heavy Duty Metal
Mounting	Wall / VESA / CDS / DIN Rail
Physical Design	- Fanless Design - Jumper-less Design
Reliability & Protection	
Reverse Power Input Protection	Yes
Over Voltage Protection	- Protection Range: 51-58V - Protection Type: shut down operating voltage, re-power on at the present level to recover
Over Current Protection	15A
CMOS Battery Backup	SuperCap Integrated for CMOS Battery Maintenance-free Operation


MTBF	216,747 Hours - Database: Telcordia SR-332 Issue3, Method 1, Case 3
Environment	
Operating Temperature	-40°C to 70°C - With extended temperature peripherals; Ambient with air flow - According to IEC60068-2-1, IEC60068-2-2, IEC60068-2-14
Storage Temperature	-40°C to 70°C
Relative Humidity	95%RH @ 70°C (non-Condensing)
Shock	Operating, 50 Grms (w/ SSD, according to IEC60068-2-27)
Vibration	- Operating, 1 Grms, 10-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-6) - Operating, 5 Grms, 5-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-64)
EMC	- CE, UKCA, FCC, ICES-003 Class A - EN IEC 61000-6-4, EN61000-6-2 (24VDC Input Only)
EMI	- CISPR 32 Conducted & Radiated: Class A - EN/BS EN 55032 Conducted & Radiated: Class A - EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A - EN/BS EN61000-3-3 Voltage fluctuations & flicker - FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	- EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV - EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 10 V/m - EN/IEC 61000-4-4 EFT: AC Power: 2 kV; DC Power: 1 kV; Signal: 1 kV - EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV - EN/IEC 61000-4-6 CS: 10V - EN/IEC 61000-4-8 PFMF: 50 Hz, 30A/m - EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 1 cycles at 60 Hz
Safety	uL, cUL, CB, IEC, EN 62368-1

** Product Specifications and features are for reference only and are subject to change without prior notice. For more information, please refer to the latest product datasheet from Cincoze's website.*

Dimensions


CS-117C/P2202

unit: mm



CS-117C/P2202E

unit: mm



1.2.4 CS-119C/P2202 Series

Model Name	CS-119C
Display	
LCD Size	• 19" (5:4)
Max. Resolution	• 1280 x 1024 (SXGA)
Brightness (cd/m2)	• 1600
Contrast Ratio	• 1000 : 1
LCD Color	• 16.7M
Pixel Pitch	• 0.294 (H) x 0.294 (V)
Viewing Angle	• 170 / 160
Backlight MTBF	• 50,000 hrs (LED Backlight)
Touchscreen	
Touchscreen Type	• Projected Capacitive
Physical	
Dimension (WxDxH)	• 510 x 389.3 x 63.2 mm
Weight	• 6.96 kg
Construction	• Flat Rugged Aluminum Die-casting Bezel
Power	
Power Consumption	• 44.45W (Max.)
Environment	
Front Panel Protection	• IP 65 Compliant
Operating Temperature	• -20°C to 70°C (With Industrial Grade Peripherals; Ambient with air flow)
Storage Temperature	• -30°C to 70°C
Relative Humidity	• 90% RH @ 40°C (non-condensing)
EMC	• CE, UKCA, FCC, ICES-003 Class A
EMI	• CISPR 32 Conducted & Radiated: Class A • EN/BS EN 55032 Conducted & Radiated: Class A • EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A • EN/BS EN61000-3-3 Voltage fluctuations & flicker • FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	• EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV • EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 3 V/m • EN/IEC 61000-4-4 EFT: AC Power: 1 kV; DC Power: 0.5 kV; Signal: 0.5 kV • EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV • EN/IEC 61000-4-6 CS: 3V • EN/IEC 61000-4-8 PFMF: 50 Hz, 1A/m • EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 0.5 cycles at 50 Hz
Safety	• UL, cUL, CB, IEC, EN 62368-1

Model Name	P2202	P2202E
System		
Processor	- Onboard 12th Generation Intel® Alder Lake-P U-Series CPU: - Intel® Core™ i5-1245UE 10 Cores Up to 4.40 GHz, TDP 15W - Intel® Core™ i3-1215UE 6 Cores Up to 4.40 GHz, TDP 15W	
Memory	2x DDR5 4800MHz SO-DIMM Socket - Supports Un-buffered and non-ECC Type, Up to 64GB	
BIOS	AMI BIOS	
Graphics		
Graphics Engine	- Integrated Intel® Iris® Xe Graphics: Core™ i5-1245UE - Integrated Intel® UHD Graphics: Core™ i3-1215UE	
Maximum Display Output	Supports Quad Independent Display	
CDS	1x CDS Connector (1920 x 1080 @60Hz)	
DP	1x DisplayPort Connector (4096 x 2304 @60Hz) * Verified maximum resolution: 3840 x 2160 @ 60Hz	
HDMI	1x HDMI Connector (3840 x 2160 @30Hz)	
VGA	1x VGA Connector (1920 x 1200 @60Hz)	
Audio		
Audio Codec	Realtek® ALC888, High Definition Audio	
Line-out	1x Line-out, Phone Jack 3.5mm	
Mic-in	1x Mic-in, Phone Jack 3.5mm	
I/O		
LAN	2x 1GbE LAN, RJ45 - GbE1: Intel® I219 - GbE2: Intel® I210	
COM	4x RS-232/422/485 with Auto Flow Control (Supports 5V/12V), DB9	
USB	3x 10Gbps USB 3.2 Gen2x1, Type A 1x 480Mbps USB 2.0, Type A	
DIO	16x Isolated Digital I/O (8in/8out), 20-Pin Terminal Block	
Storage		
SSD/HDD	2x 2.5” SATA HDD/SSD Bay (SATA3.0)	
RAID	Support RAID 0/1	
Expansion		
Mini PCI Express	2x Full-size Mini-PCIe Socket	
PCI Express	--	1x PCI or 1x PCIe x4 Expansion slot (with Optional Riser Card) * Supports maximum dimensions of add-on card (H x L):169 x 111mm
SIM Socket	1x SIM Socket	

M.2	1x M.2 Key E Type 2230 Socket, Support Intel CNVi/Wireless Module
CFM (Control Function Module) Interface	1x CFM Interface for optional IGN Module Expansion 1x CFM Interface for optional PoE Module Expansion
CDS (Convertible Display System) Interface	1x CDS Interface for Convertible Display Module
Other Function	
Clear CMOS Switch	1x Clear CMOS Switch
Reset Button	1x Reset Button
Instant Reboot	Support 0.2sec Instant Reboot Technology
Watchdog Timer	Software Programmable Supports 256 Levels System Reset
OSD Button	LCD On/Off, Brightness Up, Brightness Down
Internal Speaker	AMP 2W + 2W
Status LED Indicator	Power LED, HDD LED
Power	
Power Button	1x ATX Power On/Off Button
Power Mode Switch	1x AT/ATX Mode Switch
Power Input	9 - 48VDC, 3-pin Terminal Block
Remote Power On/Off	1x Remote Power On/Off, 2-pin Terminal Block
Max. Power Consumption	- i5-1245UE CPU: 95.06W - Test conducted with CPU, 1x RAM, and 1x storage - 100% load during burn-in testing.
Inrush Current (Peak)	i5-1245UE CPU: 5.381 A@24V
Operating System	
Windows	Windows®11, Windows®10
Linux	Ubuntu Desktop 22.04 LTS
Physical	
Dimension (W x D x H)	254.5 X 190 X 41.5 mm 254.5 x 190 x 61 mm
Weight Information	2.22 kg 2.74 kg
Mechanical Construction	Extruded Aluminum with Heavy Duty Metal
Mounting	Wall / VESA / CDS / DIN Rail
Physical Design	- Fanless Design - Jumper-less Design
Reliability & Protection	
Reverse Power Input Protection	Yes
Over Voltage Protection	- Protection Range: 51-58V - Protection Type: shut down operating voltage, re-power on at the present level to recover
Over Current Protection	15A
CMOS Battery Backup	SuperCap Integrated for CMOS Battery Maintenance-free Operation


MTBF	216,747 Hours - Database: Telcordia SR-332 Issue3, Method 1, Case 3
Environment	
Operating Temperature	-40°C to 70°C - With extended temperature peripherals; Ambient with air flow - According to IEC60068-2-1, IEC60068-2-2, IEC60068-2-14
Storage Temperature	-40°C to 70°C
Relative Humidity	95%RH @ 70°C (non-Condensing)
Shock	Operating, 50 Grms (w/ SSD, according to IEC60068-2-27)
Vibration	- Operating, 1 Grms, 10-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-6) - Operating, 5 Grms, 5-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-64)
EMC	- CE, UKCA, FCC, ICES-003 Class A - EN IEC 61000-6-4, EN61000-6-2 (24VDC Input Only)
EMI	- CISPR 32 Conducted & Radiated: Class A - EN/BS EN 55032 Conducted & Radiated: Class A - EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A - EN/BS EN61000-3-3 Voltage fluctuations & flicker - FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	- EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV - EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 10 V/m - EN/IEC 61000-4-4 EFT: AC Power: 2 kV; DC Power: 1 kV; Signal: 1 kV - EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV - EN/IEC 61000-4-6 CS: 10V - EN/IEC 61000-4-8 PFMF: 50 Hz, 30A/m - EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 1 cycles at 60 Hz
Safety	uL, cUL, CB, IEC, EN 62368-1

** Product Specifications and features are for reference only and are subject to change without prior notice. For more information, please refer to the latest product datasheet from Cincoze's website.*

Dimensions


CS-119C/P2202

unit: mm



CS-119C/P2202E

unit: mm



1.2.5 CS-W121C/P2202 Series

Model Name	CS-W121C
Display	
LCD Size	• 21.5" (16:9)
Max. Resolution	• 1920x1080 (Full HD)
Brightness (cd/m2)	• 1000
Contrast Ratio	• 5000 : 1
LCD Color	• 16.7M
Pixel Pitch	• 0.24825 (H) x 0.24825 (V)
Viewing Angle	• 178/178
Backlight MTBF	• 50,000 hrs (LED Backlight)
Touchscreen	
Touchscreen Type	• Projected Capacitive
Physical	
Dimension (WxDxH)	• 550 x 330.5 x 63.2mm
Weight	• 5.56 kg
Construction	• Flat Rugged Aluminum Die-casting Bezel
Power	
Power Consumption	• 31.25W (Max.)
Environment	
Front Panel Protection	• IP 65 Compliant
Operating Temperature	• 0°C to 80°C (With Industrial Grade Peripherals; Ambient with air flow)
Storage Temperature	• -20°C to 80°C
Relative Humidity	• 90% RH @ 40°C (non-condensing)
EMC	• CE, UKCA, FCC, ICES-003 Class A
EMI	• CISPR 32 Conducted & Radiated: Class A • EN/BS EN 55032 Conducted & Radiated: Class A • EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A • EN/BS EN61000-3-3 Voltage fluctuations & flicker • FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	• EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV • EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 3 V/m • EN/IEC 61000-4-4 EFT: AC Power: 1 kV; DC Power: 0.5 kV; Signal: 0.5 kV • EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV • EN/IEC 61000-4-6 CS: 3V • EN/IEC 61000-4-8 PFMF: 50 Hz, 1A/m • EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 0.5 cycles at 50 Hz
Safety	• UL, cUL, CB, IEC, EN 62368-1

Model Name	P2202		P2202E
System			
Processor	- Onboard 12th Generation Intel® Alder Lake-P U-Series CPU: - Intel® Core™ i5-1245UE 10 Cores Up to 4.40 GHz, TDP 15W - Intel® Core™ i3-1215UE 6 Cores Up to 4.40 GHz, TDP 15W		
Memory	2x DDR5 4800MHz SO-DIMM Socket - Supports Un-buffered and non-ECC Type, Up to 64GB		
BIOS	AMI BIOS		
Graphics			
Graphics Engine	- Integrated Intel® Iris® Xe Graphics: Core™ i5-1245UE - Integrated Intel® UHD Graphics: Core™ i3-1215UE		
Maximum Display Output	Supports Quad Independent Display		
CDS	1x CDS Connector (1920 x 1080 @60Hz)		
DP	1x DisplayPort Connector (4096 x 2304 @60Hz) * Verified maximum resolution: 3840 x 2160 @ 60Hz		
HDMI	1x HDMI Connector (3840 x 2160 @30Hz)		
VGA	1x VGA Connector (1920 x 1200 @60Hz)		
Audio			
Audio Codec	Realtek® ALC888, High Definition Audio		
Line-out	1x Line-out, Phone Jack 3.5mm		
Mic-in	1x Mic-in, Phone Jack 3.5mm		
I/O			
LAN	2x 1GbE LAN, RJ45 - GbE1: Intel® I219 - GbE2: Intel® I210		
COM	4x RS-232/422/485 with Auto Flow Control (Supports 5V/12V), DB9		
USB	3x 10Gbps USB 3.2 Gen2x1, Type A 1x 480Mbps USB 2.0, Type A		
DIO	16x Isolated Digital I/O (8in/8out), 20-Pin Terminal Block		
Storage			
SSD/HDD	2x 2.5” SATA HDD/SSD Bay (SATA3.0)		
RAID	Support RAID 0/1		
Expansion			
Mini PCI Express	2x Full-size Mini-PCIe Socket		
PCI Express	--	1x PCI or 1x PCIe x4 Expansion slot (with Optional Riser Card) * Supports maximum dimensions of add-on card (H x L):169 x 111mm	
SIM Socket	1x SIM Socket		

M.2	1x M.2 Key E Type 2230 Socket, Support Intel CNVi/Wireless Module
CFM (Control Function Module) Interface	1x CFM Interface for optional IGN Module Expansion 1x CFM Interface for optional PoE Module Expansion
CDS (Convertible Display System) Interface	1x CDS Interface for Convertible Display Module
Other Function	
Clear CMOS Switch	1x Clear CMOS Switch
Reset Button	1x Reset Button
Instant Reboot	Support 0.2sec Instant Reboot Technology
Watchdog Timer	Software Programmable Supports 256 Levels System Reset
OSD Button	LCD On/Off, Brightness Up, Brightness Down
Internal Speaker	AMP 2W + 2W
Status LED Indicator	Power LED, HDD LED
Power	
Power Button	1x ATX Power On/Off Button
Power Mode Switch	1x AT/ATX Mode Switch
Power Input	9 - 48VDC, 3-pin Terminal Block
Remote Power On/Off	1x Remote Power On/Off, 2-pin Terminal Block
Max. Power Consumption	- i5-1245UE CPU: 95.06W - Test conducted with CPU, 1x RAM, and 1x storage - 100% load during burn-in testing.
Inrush Current (Peak)	i5-1245UE CPU: 5.381 A@24V
Operating System	
Windows	Windows®11, Windows®10
Linux	Ubuntu Desktop 22.04 LTS
Physical	
Dimension (W x D x H)	254.5 X 190 X 41.5 mm 254.5 x 190 x 61 mm
Weight Information	2.22 kg 2.74 kg
Mechanical Construction	Extruded Aluminum with Heavy Duty Metal
Mounting	Wall / VESA / CDS / DIN Rail
Physical Design	- Fanless Design - Jumper-less Design
Reliability & Protection	
Reverse Power Input Protection	Yes
Over Voltage Protection	- Protection Range: 51-58V - Protection Type: shut down operating voltage, re-power on at the present level to recover
Over Current Protection	15A
CMOS Battery Backup	SuperCap Integrated for CMOS Battery Maintenance-free Operation

MTBF	216,747 Hours - Database: Telcordia SR-332 Issue3, Method 1, Case 3
Environment	
Operating Temperature	-40°C to 70°C - With extended temperature peripherals; Ambient with air flow - According to IEC60068-2-1, IEC60068-2-2, IEC60068-2-14
Storage Temperature	-40°C to 70°C
Relative Humidity	95%RH @ 70°C (non-Condensing)
Shock	Operating, 50 Grms (w/ SSD, according to IEC60068-2-27)
Vibration	- Operating, 1 Grms, 10-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-6) - Operating, 5 Grms, 5-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-64)
EMC	- CE, UKCA, FCC, ICES-003 Class A - EN IEC 61000-6-4, EN61000-6-2 (24VDC Input Only)
EMI	- CISPR 32 Conducted & Radiated: Class A - EN/BS EN 55032 Conducted & Radiated: Class A - EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A - EN/BS EN61000-3-3 Voltage fluctuations & flicker - FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	- EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV - EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 10 V/m - EN/IEC 61000-4-4 EFT: AC Power: 2 kV; DC Power: 1 kV; Signal: 1 kV - EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV - EN/IEC 61000-4-6 CS: 10V - EN/IEC 61000-4-8 PFMF: 50 Hz, 30A/m - EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 1 cycles at 60 Hz
Safety	uL, cUL, CB, IEC, EN 62368-1


** Product Specifications and features are for reference only and are subject to change without prior notice. For more information, please refer to the latest product datasheet from Cincoze's website.*

CS-W121C/P2202

NOTE:

- 1.A=14_Panel Mount hole
- 2.B=4_M3 Screw holes(6 mm Length Limits)
- 3.C=8_M4 VESA Screw holes(5 mm Length Limits)
- 4.D=6_M5 Screw holes(5 mm Length Limits)

unit: mm



NOTE:

- 1.A=14_Panel Mount hole
- 2.B=4_M3 Screw holes(6 mm Length Limits)
- 3.C=8_M4 VESA Screw holes(5 mm Length Limits)
- 4.D=6_M5 Screw holes(5 mm Length Limits)

1.2.6 CS-W124C/P2202 Series

Model Name	CS-W124C
Display	
LCD Size	• 24" (16:9)
Max. Resolution	• 1920x1080
Brightness (cd/m2)	• 1500
Contrast Ratio	• 5000 : 1
LCD Color	• 16.7M
Pixel Pitch	• 0.27675 (H) x 0.27675 (V)
Viewing Angle	• 178/178
Backlight MTBF	• 50,000 hrs (LED Backlight)
Touchscreen	
Touchscreen Type	• Projected Capacitive
Physical	
Dimension (WxDxH)	• 605 x 373 x 63.2 mm
Weight	• 6.64 kg
Construction	• Flat Rugged Aluminum Die-casting Bezel
Power	
Power Consumption	• 48.51W (Typ.)
Environment	
Front Panel Protection	• IP 65 Compliant
Operating Temperature	• -20°C to 70°C (With Industrial Grade Peripherals; Ambient with air flow)
Storage Temperature	• -30°C to 80°C
Relative Humidity	• 80% RH @ 40°C (non-condensing)
EMC	• CE, UKCA, FCC, ICES-003 Class A
EMI	• CISPR 32 Conducted & Radiated: Class A • EN/BS EN 55032 Conducted & Radiated: Class A • EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A • EN/BS EN61000-3-3 Voltage fluctuations & flicker • FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	• EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV • EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 3 V/m • EN/IEC 61000-4-4 EFT: AC Power: 1 kV; DC Power: 0.5 kV; Signal: 0.5 kV • EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV • EN/IEC 61000-4-6 CS: 3V • EN/IEC 61000-4-8 PFMF: 50 Hz, 1A/m • EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 0.5 cycles at 50 Hz
Safety	• UL, cUL, CB, IEC, EN 62368-1

Model Name	P2202		P2202E
System			
Processor	- Onboard 12th Generation Intel® Alder Lake-P U-Series CPU: - Intel® Core™ i5-1245UE 10 Cores Up to 4.40 GHz, TDP 15W - Intel® Core™ i3-1215UE 6 Cores Up to 4.40 GHz, TDP 15W		
Memory	2x DDR5 4800MHz SO-DIMM Socket - Supports Un-buffered and non-ECC Type, Up to 64GB		
BIOS	AMI BIOS		
Graphics			
Graphics Engine	- Integrated Intel® Iris® Xe Graphics: Core™ i5-1245UE - Integrated Intel® UHD Graphics: Core™ i3-1215UE		
Maximum Display Output	Supports Quad Independent Display		
CDS	1x CDS Connector (1920 x 1080 @60Hz)		
DP	1x DisplayPort Connector (4096 x 2304 @60Hz) * Verified maximum resolution: 3840 x 2160 @ 60Hz		
HDMI	1x HDMI Connector (3840 x 2160 @30Hz)		
VGA	1x VGA Connector (1920 x 1200 @60Hz)		
Audio			
Audio Codec	Realtek® ALC888, High Definition Audio		
Line-out	1x Line-out, Phone Jack 3.5mm		
Mic-in	1x Mic-in, Phone Jack 3.5mm		
I/O			
LAN	2x 1GbE LAN, RJ45 - GbE1: Intel® I219 - GbE2: Intel® I210		
COM	4x RS-232/422/485 with Auto Flow Control (Supports 5V/12V), DB9		
USB	3x 10Gbps USB 3.2 Gen2x1, Type A 1x 480Mbps USB 2.0, Type A		
DIO	16x Isolated Digital I/O (8in/8out), 20-Pin Terminal Block		
Storage			
SSD/HDD	2x 2.5” SATA HDD/SSD Bay (SATA3.0)		
RAID	Support RAID 0/1		
Expansion			
Mini PCI Express	2x Full-size Mini-PCIe Socket		
PCI Express	--	1x PCI or 1x PCIe x4 Expansion slot (with Optional Riser Card) * Supports maximum dimensions of add-on card (H x L):169 x 111mm	
SIM Socket	1x SIM Socket		


M.2	1x M.2 Key E Type 2230 Socket, Support Intel CNVi/Wireless Module
CFM (Control Function Module) Interface	1x CFM Interface for optional IGN Module Expansion 1x CFM Interface for optional PoE Module Expansion
CDS (Convertible Display System) Interface	1x CDS Interface for Convertible Display Module
Other Function	
Clear CMOS Switch	1x Clear CMOS Switch
Reset Button	1x Reset Button
Instant Reboot	Support 0.2sec Instant Reboot Technology
Watchdog Timer	Software Programmable Supports 256 Levels System Reset
OSD Button	LCD On/Off, Brightness Up, Brightness Down
Internal Speaker	AMP 2W + 2W
Status LED Indicator	Power LED, HDD LED
Power	
Power Button	1x ATX Power On/Off Button
Power Mode Switch	1x AT/ATX Mode Switch
Power Input	9 - 48VDC, 3-pin Terminal Block
Remote Power On/Off	1x Remote Power On/Off, 2-pin Terminal Block
Max. Power Consumption	- i5-1245UE CPU: 95.06W - Test conducted with CPU, 1x RAM, and 1x storage - 100% load during burn-in testing.
Inrush Current (Peak)	i5-1245UE CPU: 5.381 A@24V
Operating System	
Windows	Windows®11, Windows®10
Linux	Ubuntu Desktop 22.04 LTS
Physical	
Dimension (W x D x H)	254.5 X 190 X 41.5 mm 254.5 x 190 x 61 mm
Weight Information	2.22 kg 2.74 kg
Mechanical Construction	Extruded Aluminum with Heavy Duty Metal
Mounting	Wall / VESA / CDS / DIN Rail
Physical Design	- Fanless Design - Jumper-less Design
Reliability & Protection	
Reverse Power Input Protection	Yes
Over Voltage Protection	- Protection Range: 51-58V - Protection Type: shut down operating voltage, re-power on at the present level to recover
Over Current Protection	15A
CMOS Battery Backup	SuperCap Integrated for CMOS Battery Maintenance-free Operation

MTBF	216,747 Hours - Database: Telcordia SR-332 Issue3, Method 1, Case 3
Environment	
Operating Temperature	-40°C to 70°C - With extended temperature peripherals; Ambient with air flow - According to IEC60068-2-1, IEC60068-2-2, IEC60068-2-14
Storage Temperature	-40°C to 70°C
Relative Humidity	95%RH @ 70°C (non-Condensing)
Shock	Operating, 50 Grms (w/ SSD, according to IEC60068-2-27)
Vibration	- Operating, 1 Grms, 10-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-6) - Operating, 5 Grms, 5-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-64)
EMC	- CE, UKCA, FCC, ICES-003 Class A - EN IEC 61000-6-4, EN61000-6-2 (24VDC Input Only)
EMI	- CISPR 32 Conducted & Radiated: Class A - EN/BS EN 55032 Conducted & Radiated: Class A - EN/BS EN IEC 61000-3-2 Harmonic current emissions: Class A - EN/BS EN61000-3-3 Voltage fluctuations & flicker - FCC 47 CFR Part 15B, ICES-003 Conducted & Radiated: Class A
EMS	- EN/IEC 61000-4-2 ESD: Contact: 4 kV; Air: 8 kV - EN/IEC 61000-4-3 RS: 80 MHz to 1000 MHz: 10 V/m - EN/IEC 61000-4-4 EFT: AC Power: 2 kV; DC Power: 1 kV; Signal: 1 kV - EN/IEC 61000-4-5 Surges: AC Power: 2 kV; Signal: 1 kV - EN/IEC 61000-4-6 CS: 10V - EN/IEC 61000-4-8 PFMF: 50 Hz, 30A/m - EN/IEC 61000-4-11 Voltage Dips & Voltage Interruptions: 1 cycles at 60 Hz
Safety	uL, cUL, CB, IEC, EN 62368-1

** Product Specifications and features are for reference only and are subject to change without prior notice. For more information, please refer to the latest product datasheet from Cincoze's website.*

CS-W124C/P2202


unit: mm



NOTE:
1.A=14_Panel Mount Hole
2.B=4_M3 Screw Holes(6 mm Length Limits)
3.C=8_M4 VESA Screw Holes(5 mm Length Limits)
4.D=6_M5 Screw Holes(5 mm Length Limits)

CS-W124C/P2202E


unit: mm




NOTE:
1.A=14_Panel Mount Hole
2.B=4_M3 Screw Holes(6 mm Length Limits)
3.C=8_M4 VESA Screw Holes(5 mm Length Limits)
4.D=6_M5 Screw Holes(5 mm Length Limits)

1.3 External Layout

1.3.1 Front




CS-100/P2202




CS-100/P2202E

1.3.2 Rear




CS-100/P2202




CS-100/P2202E

1.3.3 Left




CS-100/P2202




CS-100/P2202E

1.3.4 Right



CS-100/P2202



CS-100/P2202E




Chapter 2


Introduction to Switches and Connectors

2.1 Location of Switches and Connectors

2.1.1 Top View



2.1.2 Bottom View



2.2 Switches and Connectors Definition

List of Switches and Connectors


Location	Definition
AT_ATX1	AT / ATX Power Mode Switch
BAT1	Battery Holder
BL_DN1	Backlight Decrease Button
BL_PWR1	Backlight Power on/off Button
BL_UP1	Backlight Increase Button
CAP_PH1	CAP Board to Board Connector
CN1, CN2	DDR5 SO-DIMM Socket
CN3	Mini PCI-Express Socket (Support PCIE/ USB2.0 Interface)
CN4	M.2 Key E Socket (Support PCIE / CNVi Module)
CN5	Mini PCI-Express Socket (Support PCIE/ USB3.0/ USB2.0 Interface)
COM1, COM2, COM3, COM4	COM Connector, Support RS232 / RS422 / RS485
DC_IN1	3-pin DC 9-48V Power Input Connector, with Power Ignition Connector
DIO1	Digital 8 Output Connector
DIO2	Digital 8 Input Connector
DP1	Display Port
FS_1	DC Input Power Fuse Holder
GDC1	Super CAP for CMOS Backup
IGN_PH1	IGN Control Board Female Header
JHDMI	HDMI Connector
LAN1, LAN2	Giga LAN RJ45 Connector with i219/i210
LED1	HDD / Power LED
LINE_OUT1	Line-out Jack
LVDS_OUT1	LVDS Connector
MIC_IN1	Mic-in Jack
PCIE1	PCIEx4 Slot
POE_PH1	PSE Board Male Header
POWER1, POWER2	Power Connector, Support +5V/+12V
PWR_SW1	Power Button with Power on LED
PWR_SW2	Remote Power on/off Connector
Reset1	Reset Button
RTC1	Clear COMS Switch
SATA1, SATA2	SATA Connector

CN1, CN2	SIM Card Socket
SPK_L1	Speaker out Connector for Left Side
SPK_R1	Speaker out Connector for Right Side
SW1	Super CAP Switch
SW2	COM1~4 with Power Select
USB2_1	USB 2.0 Connector
USB3_1, USB3_2, USB3_3	USB 3.2 GEN2 Connector
VGA1	VGA Connector (DB15)

2.3 Definition of Switches

AT_ATX1: AT / ATX Power Mode Switch

Switch	Definition
Left	AT Power Mode
Right	ATX Power Mode (Default)




RTC1: Clear CMOS Switch

Switch	Definition
Left	Normal (Default)
Right	Clear CMOS




BL_PWR1: Backlight Power on / off

Switch	Definition
Push	Backlight Power on / off switching




BL_UP1: Backlight Increase

Switch	Definition
Push	Backlight Increase



BL_DN1: Backlight Decrease

Switch	Definition
Push	Backlight Decrease



LED1: HDD / Power Access LED Status

Switch	Definition	LED Color
HDD LED	HDD Read/Write	Yellow
	No Operation	Colorless
POWER LED	POWER ON	Green
	POWER OFF	Colorless
	Stand by	Blinking Green



PWR_SW1: Power Button with Power on LED

Switch	Definition
Push	Power System




RESET1: Reset Button

Switch	Definition
Push	Reset System




SW2: COM1~4 with Power Select Switch


Location	Function		DIP1	DIP2
SW2	COM1	RI	ON (Default)	ON (Default)
		5V	ON	OFF
		12V	OFF	OFF




Location	Function		DIP3	DIP4
SW2	COM2	RI	ON (Default)	ON (Default)
		5V	ON	OFF
		12V	OFF	OFF



Location	Function		DIP5	DIP6
SW2	COM3	RI	ON (Default)	ON (Default)
		5V	ON	OFF
		12V	OFF	OFF



Location	Function		DIP7	DIP8
SW2	COM4	RI	ON (Default)	ON (Default)
		5V	ON	OFF
		12V	OFF	OFF



SW1: Super CAP Switch

Location	Function	DIP1	DIP2
SW1	Super CAP Enabled	ON (Default)	ON (Default)
	Super CAP Disabled	OFF	



2.4 Definition of Connectors

COM1 / COM2 / COM3/ COM4: RS232 / RS422 / RS485 Connector


Connector Type: 9-pin D-Sub

Pin	RS232 Definition	RS422 / 485 Full Duplex Definition	RS485 Half Duplex Definition
1	DCD	TX-	DATA -
2	RXD	TX+	DATA +
3	TXD	RX+	
4	DTR	RX-	
5	GND		
6	DSR		
7	RTS		
8	CTS		
9	RI		



LAN LED Status Definition


Link LED Status	Definition
Steady Green	1 Gbps Network Link
Steady Orange	100 Mbps Network Link
Off	10 Mbps Network Link
Act LED Status	Definition
Blinking Yellow	Data Activity
Steady Yellow	No Activity



DC_IN1: 3 PINs DC 9-48V power input with power ignition connector

Connector Type: Terminal Block 1x3 3-pin, 5.0mm pitch

Pin	Definition
1	+9-48VIN
2	Ignition (IGN)
3	GND



CAUTION
(ATTENTION)


Please disconnect the power source before mounting the DC power cables or connecting the DC power connector to system.

(Veuillez débrancher la source d'alimentation avant de monter les câbles d'alimentation CC ou de connecter le connecteur d'alimentation CC au système.)

POWER1 / POWER2: Power Connector, Support +5V/+12V

Connector Type: 1X4-pin Wafer, 2.0 mm pitch

Pin	Definition
1	+5V
2	GND
3	GND
4	+12V



Pin 1

PWR_SW2: Remote Power on/off Connector

Connector Type: Terminal Block 1X2 2-pin, 3.5mm pitch


Pin	Definition
1	RMT_PWR_BTN_N
2	GND



WARNING
(AVERTIR)

Do not apply power to this connector! This port is used to connect a SWITCH!


(Ne mettez pas sous tension ce connecteur! Ce port est utilisé pour connecter un SWITCH!)



DIO1: Digital Output Connector

Connector Type: Terminal Block 1X10 10-pin, 3.5mm pitch


Pin	Definition	Pin	Definition
1	XCOM+(DC INPUT)	6	DO5
2	DO1	7	DO6
3	DO2	8	DO7
4	DO3	9	DO8
5	DO4	10	XCOM-(GND)



DIO2: Digital Input Connector


Connector Type: Terminal Block 1X10 10-pin, 3.5mm pitch

Pin	Definition	Pin	Definition
1	XCOM+(DC INPUT)	16	DI5
2	DI1	17	DI6
3	DI2	18	DI7
4	DI3	19	DI8
5	DI4	20	XCOM-(GND)




CN3 : Mini PCI-Express Socket (Support PCIE/ USB2.0 Interface)

Pin No.	Pin Name	Pin No.	Pin Name
1	WAKE#	2	+3.3V
3	N/A	4	GND
5	N/A	6	+1.5V
7	CLKREQ#	8	N/A
9	GND	10	N/A
11	REFCLK-	12	N/A
13	REFCLK+	14	N/A
15	GND	16	N/A
Mechanical KEY			
17	N/A	18	GND
19	N/A	20	W_DISABLE1#
21	GND	22	PERST#
23	PERn	24	+3.3V
25	PERp	26	GND
27	GND	28	+1.5V
29	GND	30	SMB_CLK
31	PETn	32	SMB_DATA
33	PETp	34	GND
35	GND	36	USB_D-
37	GND	38	USB_D+
39	+3.3V	40	GND
41	+3.3V	42	N/A
43	GND	44	N/A
45	CLINK_CLK	46	N/A
47	CLINK_DAT	48	+1.5V
49	CLINK_RST	50	GND
51	N/A	52	+3.3V




CN5 : Mini PCI-Express Socket (Support PCIE/ USB3.0/ USB2.0 Interface)

Pin No.	Pin Name	Pin No.	Pin Name
1	WAKE#	2	+3.3V
3	N/A	4	GND
5	N/A	6	+1.5V
7	CLKREQ#	8	UIM_PWR
9	GND	10	UIM_DATA
11	REFCLK-	12	UIM_CLK
13	REFCLK+	14	UIM_RST
15	GND	16	UIM_VPP
Mechanical KEY			
17	GND	18	PERST#
19	PERn/USB3_Rn	20	+3.3V
21	PERp/USB3_Rp	22	GND
23	GND	24	+1.5V
25	GND	26	SMB_CLK
27	PETn/USB3_Tn	28	SMB_DATA
29	PETp/USB3_Tp	30	GND
31	GND	32	USB_D-
33	GND	34	USB_D+
35	+3.3V	36	GND
37	+3.3V	38	N/A
39	GND	40	N/A
41	N/A	42	N/A
43	N/A	44	+1.5V
45	N/A	46	GND
47	N/A	48	+3.3V
49	GND	50	PERST#
51	PERn/USB3_Rn	52	+3.3V



CN4 : M.2 Key E Socket (Support PCIE / CNVi Module)

Pin No.	Pin Name	Pin No.	Pin Name
1	GND	2	+3.3V
3	USB_D+	4	+3.3V
5	USB_D-	6	LED1#
7	GND	8	PCM_CLK
9	WGR_D1n	10	PCM_RSTN
11	WGR_D1p	12	PCM_IN
13	GND	14	PCM_OUT
15	WGR_D0n	16	LED2#
17	WGR_D0p	18	GND
19	GND	20	UART_WAKE#
21	WGR_CLKn	22	BRI_RSP
23	WGR_CLKp	Mechanical KEY	
33	GND	32	RGI_DT
35	PETp0	34	RGI_RSP
37	PETn0	36	BRI_DT
39	GND	38	CLINK_RST
41	PERp0	40	CLINK_DATA
43	PERn0	42	CLINK_CLK
45	GND	44	COEX3
47	REFCLKp0	46	COEX_TXD
49	REFCLKn0	48	COEX_RXD
51	GND	50	SUSCLK
53	CLKREQ0#	52	PERST0#
55	PEWAKE0#	54	W_DISABLE2#
57	GND	56	W_DISABLE1#
59	WTD1n/PETp1	58	I2C_DATA
61	WTD1p/PETn1	60	I2C_CLK
63	GND	62	ALERT
65	WTD0n/PERp1	64	REFCLK
67	WTD0p/PERn1	66	PERST1#



69	GND	68	CLKREQ1#
71	WTCLKn/REFCLKp1	70	PEWAKE1#
73	WTCLKp/REFCLKn1	72	+3.3V
75	GND	74	+3.3V


2.5 Optional Module Pin Definition & Settings

2.5.1 CFM-IGN101 Module

SW2 (on CFM-IGN101) : IGN Module Timing Setting Switch

Set shutdown delay timer when ACC is turned off

Pin 1	Pin 2	Pin 3	Pin 4	Definition
ON (IGN Enabled)	ON	ON	ON	0 second
	ON	ON	OFF	1 minute
	ON	OFF	ON	5 minutes
	ON	OFF	OFF	10 minutes
/	OFF	ON	ON	30 minutes
	OFF	ON	OFF	1 hour
	OFF	OFF	ON	2 hours
	OFF	OFF	OFF	Reserved (0 second)
OFF (IGN Disabled)				



Default setting of Pin1 to Pin4 is OFF/ON/ON/ON.

24V_12V_1 (on the system) : IGN Module Voltage Mode Setting Switch

12V / 24V Car Battery Switch

Switch	Definition
Left	24V Car Battery Input (Default)
Right	12V Car Battery Input





Chapter 3

System Setup

This chapter uses P2202 as an example to illustrate the installation of hardware components, with the exception of Chapter 3.6 and 3.17 (which demonstrates the installation of P2202E).

3.1 Removing the Top Cover



WARNING
(AVERTIR)

In order to prevent electric shock or system damage, must turn off power and disconnect the unit from power source before removing the chassis cover.

(Afin d'éviter tout risque d'électrocution ou d'endommagement du système, vous devez couper l'alimentation et débrancher l'appareil de la source d'alimentation avant de retirer le couvercle du châssis.)


Step 1. Loosen the eight screws at front and rear panel



Step 2. Raise the top cover and remove it from the chassis.




Step 3. Place the top cover aside gently.



3.2 Installing Mini PCIe Card(s)

Step 1. Locate Mini PCIe sockets on the system board.



Step 2. Use provided two screws fasten the half size module and adapter bracket together as shown in Fig (a) below.



(a) Half Size Mini-PCIe Card

(b) Full Size Mini-PCIe Card

Step 3. Tilt the Mini PCIe card at a 45-degree angle and insert it into the socket until the golden finger connector of the card seated firmly.




Step 4. Press down the card and secure it with two screws.




3.3 Installing a M.2 E Key Card

Step 1. Locate the M.2 E Key socket on the system board.



Step 2. Tilt the M.2 E Key card at a 45-degree angle and insert it to the socket until the golden finger connector of the card seated firmly.



Step 3. Press the card down and secure it with 1 screw.



3.4 Installing Antenna(s)

Step 1. Remove the antenna rubber cover on either the front, left, or right panel of the system.
(The front panel will be used for this example.)




Step 2. Penetrate the antenna jack through the hole. And then put on the washer and fasten the nut with antenna jack.



Step 3. Assemble the antenna and antenna jack together.




Step 4. Attach the RF connector at another end of the cable onto the card.



3.5 Installing SO-DIMM(s)


Step 1. Locate the SO-DIMM socket on the system board.



Step 2. Tilt the memory module at a 45-degree angle, and insert it into SO-DIMM socket until the golden finger connector of the module is seated firmly.



Lower socket



Upper socket

Step 3. Press down the memory module until retaining clips snap back in place.



Lower socket



Upper socket

3.6 Installing a PCI(e) Card

This chapter takes P2202E for example to demonstrate the installation steps.

Step 1. Loosen the two screws as indicated at rear panel.



Step 2. Attach the PCI / PCIe Card Installation Kit on, and fasten the two screws back on rear panel to fix the Kit.




Step 3. Loosen the screw as indicated to remove the PCI bracket.



Step 4. Align the notch of golden fingers of Riser card (Optional) with the slot. Insert the card vertically, and press the card straight down into the slot until it's seated firmly.




Step 5. Align the notch of golden fingers of PCI(e) card with the expansion slot. Insert the card horizontally, and press the card straight down into the slot until it's seated firmly.




Step 6. Fasten the screw back to secure the PCI(e) expansion card.




Step 7. Loosen the two screws as indicated to have the clamp arm slidable.



Step 8. Slide the clamp arm of retention module until it contacts the edge of PCI(e) expansion card.




Step 9. Finally, fasten the two screws that were previously loosen halfway to fix the retention module.



3.7 Installing Thermal Pad of Thermal Block

Step 1. Place thermal pad on the top of CPU thermal block in order to provide a seamless contact with the body of chassis to create an efficient heat dissipation.



CAUTION
(ATTENTION)

Before assembling the system's chassis cover, please make sure the protective film on the Thermal Pad has been removed!

(Avant d'assembler le capot du châssis du système, assurez-vous que le film protecteur du coussin thermique a été retiré !)

3.8 Installing the Top Cover

Step 1. Put on the edge of top cover onto system, and the other side subsequently.



Step 2. Fasten the eight screws at front and rear panel to secure the top cover.



3.9 Disassemble the CS Display Module

The complete shipping product is the CS display module already installed on the P2202. This chapter will introduce how to disassemble CS display module and P2202.

Step 1. Remove the 6 screws on the display module and disconnect the module.



3.10 Installing a SATA Hard Drive at Front Panel

Step 1. Loosen the screw to remove the HDD bay cover bracket.



Step 2. Loosen the screw as indicated on the HDD bracket.



Step 3. Pull the rotating arm of HDD bracket outward as indicated.



Step 4. Hold the rotating arm to pull out the HDD bracket.



Step 5. Place the HDD bracket on screw-hole side of HDD. Use four screws provided to assemble HDD on the bracket.



Step 6. Align the HDD bracket with the entrance of HDD bay. And insert the HDD bracket and push it until the edge connector of HDD fully inserted into SATA slot.



Step 7. Fasten the screw as indicated on the HDD bracket.




Step 8. Put back HDD bay cover at front panel, and fasten it with the screw.




3.11 Installing a SATA hard drive on Bottom Side


Step 1. Turn over the system to bottom side. Locate the cover of HDD compartment.




Step 2. Loosen the two screws, lift the cover, and then remove it.



Step 3. Loosen three screws and take the HDD bracket out of HDD compartment.



Step 4. Place the HDD bracket on screw-hole side of HDD. Use four screws provided to assemble HDD on the bracket.



Step 5. Seat the HDD bracket into HDD compartment, and line up the connector of HDD with SATA slot, then push it until HDD is fully connected into slot.



Step 6. Secure the HDD bracket with three screws.




Step 7. Put back the cover and fasten the two screws.



3.12 Installing a SIM Card

Step 1. Loosen the screw to remove the Maintenance cover bracket.



Step 2. Locate the SIM card slot.




Step 3. Insert the SIM card.




3.13 Installing CFM Modules

3.13.1 CFM-IGN101 Module

Step 1. Locate the power Ignition connector on system motherboard as indicated.



Step 2. Insert the female connector of power ignition board to the male connector on system motherboard.



Step 3. Fasten two screws to secure the power ignition board.




3.13.2 CFM-PoE04 Module

Step 1. Place a thermal pad on the top of the heatsink, and locate the two regions as marked.



Step 2. Turn over the heatsink and paste the thermal pad at the marked region.




CAUTION
(ATTENTION)


Before putting on the thermal block, please make sure the protective film on the Thermal Pad has been removed!

(Avant de mettre le bloc thermique, veuillez vous assurer que le film protecteur sur le coussin thermique a été retiré!)


Step 3. Paste the thermal pad onto the coil of the CFM-PoE module.




Step 4. Locate the PoE connector on system motherboard as indicated.



Step 5. Insert the female connector of PoE daughter board to the male connector on system motherboard.



Step 6. Put on the PoE thermal block and fasten two screws to secure the PoE board.



CAUTION
(ATTENTION)

Before assembling the system's chassis cover, please make sure the protective films on the Thermal Pads have been removed!

(Avant d'assembler le capot du châssis du système, assurez-vous que les films de protection sur les coussinets thermiques ont été retirés !)

3.14 Installing MEC Modules


This chapter takes P2202E for example to demonstrate the installation steps.

3.14.1 MEC-COM-M212-TDB9/UB1203 Module

Step 1. Loosen 2 screws on the cover plate of number 1 or 2 and then remove it. In the following steps, we use cover plate 1 for example. (You can install two MEC-USB modules for system P2202E. We only use one MEC-USB module for the example.)




Step 2. Locate one of the Mini PCIe sockets on the bottom side of the system.




Step 3. Tilt the Mini PCIe card at a 45-degree angle and insert it to the socket until the golden finger connector of the card seated firmly.




Step 4. Press the card down and secure it with 2 screws.




Step 5. Remove the 4 D-Sub jack screws from the COM ports.



Step 6. Connect the other end of the wire to the Mini PCIe card as indicated.



Step 7. Attach the COM ports onto the back side of the cover plates, and then fasten the 4 D-Sub jack screws to secure the COM ports.



Step 8. Attach the MEC-COM bracket, and fasten the 2 screws to fix it as indicated.




3.14.2 MEC-COM-M334-TDB9/UB1203 Module


Step 1. Loosen 2 screws on the cover plate of number 1 or 2 and then remove it. In the following steps, we use cover plate 1 for example. (You can install two MEC-USB modules for system P2202E)




Step 2. Locate one of the Mini PCIe sockets on the bottom side of the system.






Step 3. Tilt the Mini PCIe card at a 45-degree angle and insert it to the socket until the golden finger connector of the card seated firmly.




Step 4. Press the card down and secure it with 2 screws.



Step 5. Remove the 8 D-Sub jack screws from the COM ports.



Step 6. Connect the other end of the wire to the Mini PCIe card as indicated.



Step 7. Attach the COM ports onto the back side of the cover plates, and then fasten the 8 D-Sub jack screws to secure the COM ports.



Step 8. Attach the MEC-COM bracket, and fasten the 4 screws to fix it as indicated.




3.14.3 MEC-USB-M102-30/UB1214 Module


Step 1. Loosen 2 screws on the cover plate of number 1 or 2 and then remove it. In the following steps, we use cover plate 1 for example. (You can install two MEC-USB modules for system P2202E)




Step 2. Locate one of the Mini PCIe sockets on the bottom side of the system.



Step 3. Tilt the Mini PCIe card at a 45-degree angle and insert it to the socket until the golden finger connector of the card seated firmly.



Step 4. Press the card down and secure it with 2 screws.




Step 5. Connect the attached wire to the USB board.



Step 6. Connect the other end of the wire to the Mini PCIe card as indicated.



Step 7. Attach the USB board onto the back side of the cover plate, and then fasten the two screws to secure the module.



Step 8. Attach the MEC-USB bracket, and fasten the 2 screws to fix it as indicated.




3.14.4 MEC-LAN-M102-30/UB1211 Module


Step 1. Loosen 2 screws on the cover plate of number 1 or 2 and then remove it. In the following steps, we use cover plate 1 for example. (You can install two MEC-LAN modules for system P2202E)




Step 2. Locate one of the Mini PCIe sockets on the bottom side of the system.



Step 3. Tilt the Mini PCIe card at a 45-degree angle and insert it to the socket until the golden finger connector of the card seated firmly.




Step 4. Press the card down and secure it with 2 screws.



Step 5. Connect the attached wires to the LAN board.



Step 6. Connect the wires to the Mini PCIe card as indicated.



Step 7. Attach the LAN board onto the back side of the cover plate, and then fasten the two screws to secure the module.




Step 9. Attach the MEC-LAN bracket, and fasten the 2 screws to fix it as indicated.




3.15 Installing Panel Mount

1. Accessories provided by Cincoze are as below. (Please note that the quantity of mounting kits varies with the size of the display module, please refer to the datasheet for the actual quantity)




Mounting Kits




Panel Mount PPC


Panel Mount with customer's fixture
(Front View)




2. All mounting kits displayed are to be inserted into holes.




3. Installation preparation and steps.




Panel mount side view with LVDS connector of CS series




Before Mounting Kits are installed




Position panel mount kits



Insert the panel mounting kit into bottom hole




Slide the kit toward back




Tighten the screw forward until the front screw just touches the surface

4. Apply all mount kits to the rest of holes. And you have completed the panel mount installation, as shown below.



3.16 Installing VESA Mount

The following picture indicates VESA mounting hole pattern on the P2202, which is compliant with VESA mounting standard.



Step 1. The following picture uses a panel PC (P2202+ Display Module) as a demonstration. To attach the panel PC to a VESA stand, please fasten eight screws as indicated to fix it on the stand.




3.17 Installing Rack Mount

Step 1. Locate the screw holes on the PC or monitor module. Then fasten 8 screws (M4x6) as indicated to fix it on the rack mount base.



Step 2. Assemble two rack mount brackets by fastening 4 screws (M5x6) at each side.


For 8.4" ~ 17" Panel PC



Left Side




Right Side



Bottom Side

For 19" ~ 24" Panel PC



Left Side




Right Side




Bottom Side

Step 3. Assemble two rack mount brackets by fastening 4 screws (M5x12), flat washers and hex nuts at each side.



For 8.4" ~ 17" Panel PC



For 19" ~ 24" Panel PC

A vertical bar on the left side of the page, consisting of a yellow upper half and a black lower half.

Chapter 4

BIOS Setup

4.1 BIOS Introduction

The BIOS (Basic Input/ Output System) is a program located on a Flash Memory on the motherboard. When you start the computer, the BIOS program will gain control. The BIOS first operates an auto-diagnostic test called POST (power on self-test) for all the necessary hardware, it detects the entire hardware device and configures the parameters of the hardware synchronization.

BIOS Setup

Power on the computer and by pressing immediately allows you to enter Setup. If the message disappears before your respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing <Ctrl>, <Alt> and <Delete> keys.

Control Keys	
<←> <→>	Move to select screen
<↑> <↓>	Move to select item
<Esc>	Quit the BIOS Setup
<Enter>	Select item
<Page Up/+>	Increases the numeric value or makes changes
<Page Down/->	Decreases the numeric value or makes changes
<Tab>	Select setup fields
<F1>	General help
<F2>	Previous value
<F3>	Load Optimized defaults
<F10>	Save configuration and Exit

Main Menu


The main menu lists the setup functions you can make changes to. You can use the arrow keys (↑ ↓) to select the item. The on-line description of the highlighted setup function is displayed at the bottom of the screen.

Sub-Menu

If you find a right pointer symbol appears to the left of certain fields that means a sub-menu can be launched from this field. A sub-menu contains additional options for a field parameter. You can use arrow keys (↑ ↓) to highlight the field and press <Enter> to call up the sub-menu. Then you can use the control keys to enter values and move from field to field within a sub-menu. If you want to return to the main menu, just press the <Esc >.

4.2 Main Setup

Press to enter BIOS CMOS Setup Utility, the Main Menu (as shown below) will appear on the screen. Use arrow keys to move among the items and press <Enter> to accept or enter a sub-menu.




4.2.1 System Date

Set the date. Please use <Tab> to switch between date elements.


4.2.2 System Time

Set the time. Please use <Tab> to switch between time elements.

4.3 Advanced Setup



4.3.1 CPU Configuration



■ Intel® (VMX) Virtualization Technology [Enabled]

Enables or disables Intel® Virtualization Technology. Virtualization enhanced by Intel® Virtualization Technology will allow a platform to run multiple operating systems and applications in independent partitions. With virtualization, one computer system can function as multiple virtual systems.

■ Active Performance-cores [All]

Allows you to choose the number of active performance cores.

Configuration options: [All] [1]

■ Active Efficient-cores [All]


Allows you to choose the number of active efficient cores.

Configuration options: [All] [1] [2] [3] [4] [5] [6] [7]

■ Hyper-Threading [Enabled]

Allows you to enable or disable Intel® Hyper-Threading function of processor.

4.3.2 SATA Configuration



■ SATA Controller(s) [Enabled]

Enables or disables Serial ATA controller.

■ SATA Mode [AHCI]

This item allows users to choose [AHCI] mode.

■ Serial ATA Port 0

Port 0 [Enabled]


Enables or disables SATA Port 0.

■ Serial ATA Port 1


Port 1 [Enabled]

Enables or disables SATA Port 1.

4.3.3 PCH-FW Configuration




❑ Firmware Update Configuration



■ ME FW Image Re-Flash [Disabled]

Allows you to enable or disable ME firmware image re-flash function.

4.3.4 Trusted Computing



■ Security Device Support [Enable]

Allow you to enables or disables Security Device Support function.

■ SHA256 PCR Bank [Enabled]

Enables or disables SHA256 PCR Bank function.

■ SHA384 PCR Bank [Disabled]

Enables or disables SHA384 PCR Bank function.

■ SHA3_256 PCR Bank [Disabled]

Enables or disables SHA3_256 PCR Bank function.

■ Pending Operation [None]

Allows users to select which mode Pending Operation will operate.

Configuration options: [None], [TPM Clear]

- **Platform Hierarchy [Enabled]**

Enables or disables Platform Hierarchy function.

- **Storage Hierarchy [Enabled]**

Enables or disables Storage Hierarchy function.

- **Endorsement Hierarchy [Enabled]**

Enables or disables Endorsement Hierarchy function.


- **Physical Presence Spec Version [1.3]**

Allows users to select which mode Physical Presence Spec Version will operate.

Configuration options: [1.2], [1.3]

4.3.5 ACPI Settings

This item allows users to configure ACPI settings.



- **Enable ACPI Auto Configuration [Enabled]**

Enables or disables BIOS Advanced Configuration Power Interface® (ACPI) auto configuration.

- **ACPI Sleep State [S3 (Suspend to RAM)]**


Allows users to select the highest Advanced Configuration Power Interface® (ACPI) sleep state that system will enter when suspend button is pressed.

[Suspend Disabled]: Disables entering suspend state.


[S3 (suspend to RAM)]: Enables suspend to RAM state.

4.3.6 F81966 Super IO Configuration

The screen allows users to select options for the Super IO configuration, and change the value of the selected option.



Serial Port 1~4 Configuration



- **Serial Port [Enabled]**
This item allows users to enable or disable serial port.
- **Change Settings [Auto]**
This item allows users to change the address & IRQ settings of the specified serial port.
- **Onboard Serial Port 1 Mode [RS232]**
This item allows users to select Serial Port Mode.
Configuration options: [RS232] [RS422/RS485 Full Duplex] [RS485 Half Duplex]
- **Watch Dog [Disabled]**

Enables or disables watch dog function.

■ **Watch Dog Mode [Sec]**


Changes the Watch dog mode. Select [Sec] or [Min] mode.

■ **Watch Dog Timer [0]**

User can set a value in the range of 0 to 255.

4.3.7 Hardware Monitor

These items display the current status of all monitored hardware devices/ components such as voltages and temperatures.




■ **Internal Smart Fan Function [Enabled]**

Enables or disables internal smart fan function. Please install the Riser Card (Model: RC-E4-02) and plug the power cord of the internal smart fan into the power socket on the Riser Card to effectively enable this function.

□ **Internal Smart Fan Configuration**

Allows users to setting internal smart fan parameters.




■ Smart Fan Mode [Auto]

This item allows users to select Auto or Manual for smart fan mode.

■ Fan Speed Mode [RPM]

This item allows users to select RPM or Duty for fan speed mode.

4.3.8 S5 RTC Wake Settings




■ Wake System from S5 [Disabled]

This item allows users to change the way to wake system from S5 state.

[Fixed Time]: Set the specified time (HH:MM:SS) to wake system.

[Dynamic Time]: Set the increase time from current time to wake system.


4.3.9 Serial Port Console Redirection



■ Console Redirection [Disabled]

These items allow users to enable or disable COM0, COM1, COM2, Com3 console redirection function.

4.3.10 USB Configuration




■ XHCI Hand-off [Enabled]

This item allows users to enable or disable XHCI (USB3.2) hand-off function.

■ USB Mass Storage Driver Support [Enabled]

Enables or disables support for USB mass storage devices.


4.3.11 Network Stack Configuration



■ Network Stack [Disabled]

Enables or disables UEFI Network Stack.

4.3.12 CSM Configuration




■ CSM Support [Disabled]


This item allows users to enable or disable UEFI Compatibility Support Module (CSM) to support a legacy PC boot process.

4.4 Chipset Setup

This section allows you to configure chipset related settings according to user's preference.




4.4.1 System Agent (SA) Configuration



❑ Memory Configuration


This item displays detailed memory information in the system.



■ Max TOLUD [Dynamic]

This item allows users to select maximum value of TOLUD.

❑ Graphics Configuration



■ Primary Display [Auto]

Allows users to select which graphics device should be primary display or select SG for switchable graphics. Configuration options: [Auto] [IGFX] [PEG Slot] [PCIe]

■ Internal Graphics [Auto]

This item allows users to enable or disable Internal Graphics. When set to [Auto], it will detect by BIOS. Configuration options: [Auto] [Disabled] [Enabled]


❑ VMD Setup Menu




■ Enable VMD controller [Disabled]

This item allows users to enable or disable VMD controller. Enable this function can support creating RAID.

❑ PCI Express Configuration



❑ PCI Express Configuration



■ PCI Express Root Port [Enabled]

Allows you to enable or disable the PCI Express Port.

■ PCIe Speed [Auto]


Allows you to select PCI Express interface speed.

Configuration options: [Auto] [Gen1] [Gen2] [Gen3] [Gen4].


❑ VT-d [Enabled]

This item allows users to enable or disable Intel® Virtualization Technology for Directed I/O (VT-d) function.

4.4.2 PCH-IO Configuration



☐ PCI Express Configuration



☐ PCI Express Root Port(CN5)

☒ PCI Express Root Port [Enabled]

Allows you to enable or disable the PCI Express Port.

☒ PCIe Speed [Auto]

Allows you to select PCI Express interface speed.

Configuration options: [Auto] [Gen1] [Gen2] [Gen3].

☐ PCI Express Root Port(CN3)

☒ PCI Express Root Port [Enabled]

Allows you to enable or disable the PCI Express Port.

☒ PCIe Speed [Auto]

Allows you to select PCI Express interface speed.

Configuration options: [Auto] [Gen1] [Gen2] [Gen3].

☐ **PCI Express Root Port(CN4)**

■ **PCI Express Root Port [Enabled]**


Allows you to enable or disable the PCI Express Port.

■ **PCIe Speed [Auto]**

Allows you to select PCI Express interface speed.

Configuration options: [Auto] [Gen1] [Gen2] [Gen3].

☐ **HD Audio Configuration**



■ **HD Audio [Enabled]**

Allows you to select HD Audio options.

[Enabled]: HD Audio device is unconditionally enabled.

[Disabled]: HD Audio device is unconditionally disabled.

■ **LAN i219LM Controller [Enabled]**

Enables or disables i219LM LAN Controller.

■ **Wake On LAN (i219) [Enabled]**

Enables or disables integrated LAN i219LM Wake On LAN function.

■ **LAN i210AT Controller [Enabled]**

Enables or disables i210 LAN Controller.

■ **Wake# event (PCIe) [Enabled]**

Enables or disables integrated LAN i210 Wake On LAN function.

■ **CN5 Function Switch [Mini-PCIe]**

Select Mini-PCIe/USB3.0 for CN5 connector.

■ **CN4 Function Switch [Wifi]**

Select CNV/Wifi(PCIe) for CN4 connector.

■ **Audio Amplifier [Enabled]**

Enable or disable Audio Amplifier.

■ Power Over Ethernet Function [Enabled]

Enable or disable Power Over Ethernet (POE) function.

■ Power Failure [Keep last state]

Allows you to specify which power state system will enter when power is resumed after a power failure (G3 state).


[Always on]: Enters to power on state.

[Always off]: Enters to power off state.

[Keep last state]: Enters to the last power state before a power failure.

4.5 Security Setup

This section allows users to configure BIOS security settings.




4.5.1 Administrator Password

Administrator Password controls access to the BIOS Setup utility.

4.5.2 User Password

User Password controls access to the system at boot and to the BIOS Setup utility.


4.5.3 Security Boot



- ☐ **Secure Boot [Disabled]**
Enable or disable Secure Boot function.
- ☐ **Secure Boot Mode [Standard]**
Allows you to select Secure Boot Mode.
Configuration options: [Standard] [Custom].

4.6 Boot Setup

This section allows you to configure Boot settings.



4.6.1 Setup Prompt Timeout [1]

Use this item to set number of seconds (1..65535) to wait for setup activation key.

4.6.2 Bootup NumLock State [Off]

Allows you to select the power-on state for keyboard NumLock.


4.6.3 Quiet Boot [Disabled]

Allows you to enable or disable Quiet Boot function.

4.6.4 Fast Boot [Disabled]

Allows you to enable or disable Fast Boot function.

4.7 Save & Exit



4.7.1 Save Changes and Exit

This item allows you to exit system setup after saving changes.

4.7.2 Discard Changes and Exit

This item allows you to exit system setup without saving changes.

4.7.3 Save Changes and Reset

This item allows you to reset the system after saving changes.

4.7.4 Discard Changes and Reset

This item allows you to reset system setup without saving any changes.

4.7.5 Save Changes

This item allows you to save changes done so far to any of the setup options.

4.7.6 Discard Changes

This item allows you to discard changes done so far to any of the setup options.

4.7.7 Restore Defaults

This item allows you to restore/ load default values for all the options.

4.7.8 Save as User Defaults


This item allows you to save the changes done so far as user defaults.

4.7.9 Restore User Defaults


This item allows you to restore the user defaults to all the options.

4.8 MEBx


This page is for ME function setting. Press the delete key to enter the BIOS menu then user can see the following MEBx page.




Press enter key to enter the default password "admin" to enter the next step for password creation.




Create a new password using 8 characters including uppercase and lowercase letters, numbers and special symbols.



Enter the created password again for confirmation.



Then you can see the function setting page of MEBx.





Chapter 5

Product Application

5.1 Where to download drivers?

Drivers for the CS-100/P2202 Series can be downloaded from the CINCOZE website.

5.2 Where to find the technical documents?

The following documents are the most relevant technical references for the CS-100/P2202 Series. All documents can be accessed via the CINCOZE Partner Zone:

- **Application Notes:** Navigate to *Home > Partner Zone > Technical Support > Application Notes*.
- **Configure & Installation:** Navigate to *Home > Partner Zone > Technical Support > Configure & Installation*.
- **Other Product Information:** Navigate to *Home > Partner Zone > Product Center > Product Information > Industrial Panel PC & Monitor > Sunlight Readable Panel PC > High Performance Sunlight Readable Panel PC > CS-100/P2202 Series*.

Catalog	Document Title
Application Notes	DIO Application Guide
	DIO Technical Guide
	Instant Reboot Application Guide
	WDT Application Guide
	WDT Technical Guide
Configure & Installation	AT ATX Function Manual
	BIOS Administrator User Password Function Manual
	Clear CMOS Function Manual
	COM Function Manual
	CSM Function Manual
	Digital I/O Function Manual
	How to import Secure Boot Key?
	How to restore Windows image with Clonezilla?
	How to set TPM function under Windows?
	How to stop automatic driver update in Windows SOP
	How to Update BIOS and ME under UEFI shell?
	How to Update BIOS under UEFI shell?
	How to Update BIOS under Windows?
	IGN Module User Manual
	Intel AMT with KVM Remote Control
	POE Module User Manual
	PXE Function Manual
	RAID Function Manual
	Remote Switch Function Manual

	Wake On LAN Function Manual
	WDT Function Manual



© 2023 Cincoze Co., Ltd. All rights reserved.

The Cincoze logo is a registered trademark of Cincoze Co., Ltd.

All other logos appearing in this catalog are the intellectual property of the respective company, product, or organization associated with the logo.

All product specifications and information are subject to change without notice.